

Part Routing Notes

For part #: ALL

Note #	Part #	Note Text	Next Note #
002	11000	ATTACH CABLE # 13700 TO POWER SUPPLY	003
003	11000	PRESS FIRMLY!!!!	004
004	11000	ADD A LINE	
001	11000	ASSEMBLE POWER SUPPLY TO CHASSIS USING TOOL # 3409D	002
002	12100	PAT SPECIAL ATTENTION TO THE CABLE ROUTING PER PRINT	
001	12100	ASSEMBLE PER ASSOCIATED DOCUMENT 12100ASSMPRO.DOC	002
001	12210	This is a test of routing notes for part 12210	003
003	12210	This is also a test of line 3	
002	22100	PAT SPECIAL ATTENTION TO THE CABLE ROUTING PER PRINT	
001	22100	ASSEMBLE PER ASSOCIATED DOCUMENT 12100ASSMPRO.DOC	002
002	40000	INSERT USING FIXTURE 45- J97	003
003	40000	WIPE CLEAN WITH A DAMP SOFT RAG	
001	40000	PREPARE RUBBER BLADE BY COATING WITH PRE-HYDROGENATED VEGATABLE OIL	002
001	PART123	This is a test for PART123	